

Share Your Knowledge

If you are an expert in your field of electronics, why not share your knowledge with the world?



Electronics For You invites electronics professionals and industry experts to write articles on their area of expertise and interest from different perspectives

Some of the topics we want you to write about are:

- Photonics: Optics & Optoelectronics
- Automation
- Power Electronics
- Components
- Telecom

So if you have an interesting topic or original article to share, please let us know at efyeditorial@efy.in

We would love to hear your good ideas too!

electronics
FOR YOU




Fig. 5: Block diagram of a general frequency meter with reciprocal counting




Fig. 6: Simplified block diagram of the line-frequency meter

Principle of operation

A generalised frequency meter with reciprocal counting is shown in Fig. 5.

An exact number of input cycles are counted in event counter and, simultaneously, the reference clock is counted in time counter for the same duration.

An equation can be written as:

$$N_s \times T_s = N_r \times T_r$$

where N_s is the number of cycles of the input frequency (50 counts in this case) and T_s is the period of the input signal. N_r is the number of cycles of the reference frequency counted within this time and T_r is the period of the reference clock (0.2 milliseconds or 0.2ms in this case).

Frequency of signal is given by:

$$F_s = 1/T_s = N_s / (N_r \times T_r) \\ = 50 / (N_r \times 0.2\text{ms}) = 250000/N_r$$

If line frequency is exactly 50Hz, this equation will give:

$$F_s = (250000/5000) = 50$$

That is, to obtain a resolution of 0.01Hz, value in the display will be 50.00.

Arduino Uno is an excellent

platform for the measurement of line frequency using the reciprocal counting method. A simplified block diagram of the line-frequency meter is shown in Fig. 6.

In this figure, line-voltage sine-wave is converted into a square wave of TTL levels using only a transistor. This is sufficient because the event counter counts only integral cycles and that eliminates zero-crossing errors. This square wave is applied to port pin 6 of Arduino Uno.

Square-wave cycles are counted by the software and the event counter. Clock frequency for the time counter is obtained from Arduino itself by the use of `Tone()` function in the Arduino code as explained in software section. This signal is applied to counter T1.

1. Event counter software counts exactly 50 cycles of the input signal.

2. Time counter simultaneously counts the number of reference pulses.

3. A simple reciprocal calculation then finds the frequency.

A counter similar to the circuits based on ICL7217 or NS74C926 can